



ZigZag – Sliding Folding Walls

Operation & Maintenance Manual

www.creatif.org.uk

02_Contents

Thank you for choosing ZigZag by Creatif - our sliding folding wall system.

This guide is designed to walk you through how to use the ZigZag moving wall system.

For technical drawings, please contact Creatif.

Page 03-07	Operation Guide
Page 08	Cleaning & Maintenance
Page 09	Contact

Servicing

Do you have a problem with your moving wall system or do you want to ask a question?

Email: service@creatif.org.uk

Guarantees

All materials were supplied by, or on behalf of, Creatif and manufactured in our factory.

All materials are guaranteed for 12 months from the date of installation, with the exception of component failure caused as a result of misuse or neglect.

03_Operation Guide 1 of 5


Operating ZigZag is like riding a bike - when you've done it once, you'll never forget how to do it...

This guide assumes ZigZag is in the closed position (forming a wall). If your system is in the closed position (i.e. the panels are stacked away), simply perform the following steps in reverse order.

Step 1

Locate and open your Pass Door.

Push the Pass Door completely back on itself until you feel it magnetise to next panel in the set.




04_Operation Guide 2 of 5

Step 2

With the Pass Door safely in place, open all of the escutcheons on your system by sliding them to the left.


Please note that the number of escutheons present will depend on the size of your wall - no two ZigZag systems are the same!



05_Operation Guide 3 of 5

Step 3


Insert your Turning Key into the slot now visible (thanks to moving the escutcheon) and turn clockwise - repeat this step for all slots.



06_Operation Guide 4 of 5

Step 4

Once you've unlocked all the panels, push against the panels adjacent to the hinges with your hand - this will cause the panels to fold.



07_Operation

Guide 5 of 5

Step 5

Once the panels have all folded, go back to the Pass Door and hold with one hand on each side.

Gently push the panels back towards the stacking area.



08_Cleaning & Maintenance

ZigZag requires very little attention, with the obvious exception of keeping the track free of dirt and objects.

All systems featuring panels with a standard finish can be cleaned with a damp cloth and dried with a dry cloth immediately after.

Side profiles and the acoustic seals can be cleaned with a damp cloth and, again, should be dried with a dry cloth.

We recommend that you avoid scrubbing and the use of bleach-based cleaning products.

For more information on a service contract, system usage or to activate your warranty, give us a call or send an email:

service@creatif.org.uk



09_Contact

If you have any questions about your moving wall system, or would like to find out more about our servicing packages, please get in touch:

T: +44 (0) 113 270 1239

E: service@creatif.org.uk

www.creatif.org.uk



**Do you have
a question?**

Want to discuss
servicing options?

Get in touch!